AIRPORT DIAGRAM
24305

DANIEL K INOUYE INTL (HNL) (PHNL)
HONOLULU, HI

AL-754 (FAA)

D-ATIS
127.9 251.15
HONOLULU TOWER
118.1 257.8
123.9 273.575 (RWY 08R-26L)
GND CON
121.9 348.6
GND CON (RAMP CON)
121.8
CLNC DEL
121.4 281.4
PDC
D

157°57'W 157°56'W 157°55'W

21°20'N

21°19'N

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all surfaces.

VAR 9.5° E
JANUARY 2020
ANNUAL RATE OF CHANGE
0.0° E

JOINT BASE PEARL HARBOR-HICKAM
BASE OPS
HICKAM RAMP ADVISORY
TERMINAL
AIR FREIGHT
FIRE STATION
TRAN ALERT
HAWAII ANG
FIELD ELEV 14
ATC NON-VISIBILITY AREA
HAZARDOUS CARGO PAD
FIRE STATION
BCN
TWR 190
ELEV 10
BAK-12/14
GENERAL AVIATION CARGO
FIRE STATION
CALIBRATION PAD
LAHSO
ELEV 8
ELEV 9
ELEV 0
ELEV 10

HS 1
HS 2
HS 3
HS 4

080.5°
260.5°
043.5°
223.5°
221.5°
041.5°
081.5°
261.5°

12360 X 200
695 X 150
9002 X 150
3000 X 150
5090 X 300
12000 X 200

HIRL Rwys 8L-26R, 4R-22L and 8R-26L
MIRL Rwy 4L-22R
REIL Rwys 26R, 22L, 8R, 4L and 22R

RWY 04L-22R
PCN 31 F/B/X/T
S-100, D-200, 2D-400, 2D/2D2-850
RWY 04R-22L
PCN 57 F/B/X/T
S-100, D-200, 2D-400, 2D/2D2-850
RWY 08L-26R
PCN 79 R/B/W/T
S-100, D-200, 2D-400, 2D/2D2-780
RWY 08R-26L
PCN 98 F/B/X/T
S-80, D-170, 2D-400, 2D/2D2-780