

ILS RWY 14R (SA CAT I)
EPPLEY AIRFIELD (OMA)

MISSED APPROACH: Climb to 1900 then climbing left turn to 3000 direct OVR VORTAC and hold.

Requires specific OPSPEC, MSPEC or LOA approval and use of HUD to DA.



MSA OVR 25 NM

4100

(IF) OTSEE
I-OMA 12.2
RADAR

2400 NoPT
142° (6.2)

(IAF) ZATAR
I-OMA 6
6000

LOCALIZER 110.3
I-OMA
Chan 40

ALTERNATE MISSED
APCH FIX

PLATTSMOUTH
PMV
329

ELEV 985 **D** TDZE 985

OMAHA
116.3 OVR
Chan 110

Procedure NA for arrival
on OVR VORTAC airway
radials 258 CW 332.

SA CATEGORY I ILS - SPECIAL AIRCREW
& AIRCRAFT CERTIFICATION REQUIRED

ILS RWY 14R (SA CAT I)