


VOR or TACAN RWY 5
FORT WAYNE INTL (FWA)

MISSED APPROACH: Climbing right turn to 3000 on FWA VORTAC R-134 to OSBER INT/FWA 22 DME and hold.



Procedure NA for arrival on FWA VORTAC
airway radials 198 CW 294.



One Minute Holding Pattern					
CATEGORY	A	B	C	D	E
S-5	1320/24	505 (600 - ½)	1320/55	505 (600-1)	1320/60 505 (600-1¼)
CIRCLING	1320-1	505 (600-1)	1360-1½ 545 (600-1½)	1520-2¼ 705 (800-2½)	1520-2½ 705 (800-2½)