

DME required.		MISSED APPROACH: Climbing right turn to 2200 direct CTF VOR/DME and hold.
AWOS-3 118.225	SHAW APP CON ★ 125.4 318.1	UNICOM 122.8 (CTAF) 0

