

ILS Y or LOC Y RWY 17
MAJORS (GVT)

T
A

MALS



MISSED APPROACH: Climbing
right turn to 3000 on MJF
TACAN R-186 to CAJAN/MJF
TACAN 15 DME and hold.

BONHAM
114.6 BYP
Chan 93

3000
148° (14.9)

7 NM

167°

347°

(IAF) WOLFI MUF 15

2200 to ENDUE
126° (2.7) and 176° (2)

336°

(IF) ENDUE I-GVT 11.9

2200
176° (5.3)

1249
A

815
A

POCNI I-GVT 6.7

755
A

1039
A

R-186

ARVILLA
Chan 33
MUF 109.6 (109.6)

LOCALIZER 110.5
I-GVT
Chan 42

ELEV 535

TDZE 534

176° 5.1 NM from FAF

4% UP

MSA MUF 25 NM
2400

EMERG SAFE ALT 100 NM 4000

3000 to WOLFI
276° (29)

SULPHUR SPRINGS
109.0 SLR
Chan 27

MISSED APCH FIX
CAJAN MUF 15
R-186
MUF 15
Chan 33
006°
186°

**FOR MILITARY AIRCRAFT ONLY,
TACAN REQUIRED**

REIL Rwy 35
MRL Rwy 17-35