

|                                        |                        |                                                                 |
|----------------------------------------|------------------------|-----------------------------------------------------------------|
| WAAS<br>CH <b>45618</b><br><b>W11A</b> | APP CRS<br><b>113°</b> | Rwy Idg <b>6200</b><br>TDZE <b>2976</b><br>Apt Elev <b>3004</b> |
|----------------------------------------|------------------------|-----------------------------------------------------------------|

RNAV (GPS) RWY 11

ODESSA-SCHLEMEYER FLD (ODO)

⚠

Circling to Rwy 16 and 20 NA at night. For uncompensated Baro-VNAV systems, LNAV/VNAV NA below -20°C (-4°F) or above 54°C (130°F). DME/DME RNP-0.3 NA. Circling NA S of Rwys 2 and 34. When local altimeter setting not received use Midland Intl Air and Space Port altimeter setting and increase all DA 41 feet and all MDA 60 feet and increase LNAV/VNAV all Cats visibility 1⁄8 mile, LNAV Cat C and D and Circling Cat C visibility 1⁄4 mile. VDP NA with Midland Intl Air and Space Port altimeter setting. Baro-VNAV NA when using Midland Intl Air and Space Port altimeter setting.

MALS

MISSED APPROACH:

Climb to 5000 direct JEMBI and hold.

|                        |                                           |                          |                               |
|------------------------|-------------------------------------------|--------------------------|-------------------------------|
| ASOS<br><b>119.275</b> | MIDLAND APP CON ★<br><b>124.6 256.875</b> | CLNC DEL<br><b>121.7</b> | UNICOM<br><b>123.0</b> (CTAF) |
|------------------------|-------------------------------------------|--------------------------|-------------------------------|

