

ILS Z or LOC Z RWY 11
KETCHIKAN INTL (KTN)(PAKT)

MALSR 	MISSED APPROACH: Climb to 5000 direct CMJ NDB and on CMJ NDB bearing 124° to UCARU/I-ECH 6.6 DME and on ANN VOR/DME R-338 to ANN VOR/DME and hold.
	#S-ILS 11 missed approach requires minimum climb of 305 feet per NM to 4000. S-LOC 11 missed approach requires minimum climb of 235 feet per NM to 4000. If unable to meet climb gradients, see LOC X RWY 11.

