



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 5: Climb heading 055° to 1700 before turning right, thence. . . .
TAKEOFF RWYS 18C/L: Climb heading 183°, thence. . . .
TAKEOFF RWY 18R: Climbing right turn heading 200°, thence. . . .
TAKEOFF RWY 23: Climb heading 235°, thence. . . .
TAKEOFF RWY 36C: Climb heading 003° to 1400 then left turn heading 330°,
thence. . . .
TAKEOFF RWY 36L: Climb heading 003° to 1800 then left turn heading 315°,
thence. . . .
TAKEOFF RWY 36R: Climbing right turn heading 025°, thence. . . .

. . . .on RADAR vectors to intercept filed/assigned transition or enroute fix/navaid.
Maintain 8000, expect filed altitude/flight level 10 minutes after departure.

ANDYS TRANSITION (KER3.ANDYS): From over CLT VOR/DME on CLT R-196 to ANDYS.
DEBIE TRANSITION (KER3.DEBIE): From over CLT VOR/DME on CLT R-255 to DEBIE.
HAMLN TRANSITION (KER3.HAMLN): From over CLT VOR/DME on CLT R-175 to HAMLN.
JOTTA TRANSITION (KER3.JOTTA): From over CLT VOR/DME on CLT R-011 to JOTTA.
LILLS TRANSITION (KER3.LILLS): From over CLT VOR/DME on CLT R-112 to LILLS.
MERIL TRANSITION (KER3.MERIL): From over CLT VOR/DME on CLT R-076 to MERIL.
NALEY TRANSITION (KER3.NALEY): From over CLT VOR/DME on CLT R-011 to NALEY.
NEANO TRANSITION (KER3.NEANO): From over CLT VOR/DME on CLT R-275 to BOBZY
and ODF R-070 to NEANO.
TREAL TRANSITION (KER3.TREAL): From over CLT VOR/DME on CLT R-196 to TREAL.