


AWOS-3
135.425
WHIDBEY DEP CON
118.2 285.65 (SOUTH)
VICTORIA DEP CON
132.7 290.8 (NORTH)
CTAF
128.25

TOP ALTITUDE:
3000

NOTE: GPS required.
NOTE: RADAR required.
NOTE: RNAV 1.



TAKEOFF MINIMUMS
Rwy 16: 400-1 with minimum climb of
500' per NM to 1900 or
standard with minimum climb
of 901' per NM to 600.

NOTE: Chart not to scale.

DEPARTURE ROUTE DESCRIPTION
TAKEOFF RUNWAY 16: Climb heading 163° to 1900 then direct FEGBA. Expect
RADAR vectors on assigned route.