

VOR RWY 17L
WILEY POST (PWA)

MISSED APPROACH: Climb to 1700 then climbing left turn to 3000 direct IRW VORTAC and hold.



Procedure NA for arrival on IRW
VORTAC airway radials 292 CW 045.

WILL ROGERS
114.1 IRW
Chan 88

1700
3000
IRW

PWA
VOR/DME
PWA 1.7

176°
356°
176°

2800
2800

3.5 NM
3.00°
TCH 54

169°
348°
158°

10 to MCLAN
(15.8)

MCLAN
PWA 5.3

6000

Remain within 10 NM

CATEGORY	A	B	C	D
S-17L	1680-½ 389 (400-½)		1680-⅝ 389 (400-⅝)	