

|                                                     |                        |                                                     |
|-----------------------------------------------------|------------------------|-----------------------------------------------------|
| LOC/DME I-HNQ<br><b>108.75</b><br>Chan <b>24(Y)</b> | APP CRS<br><b>174°</b> | Rwy Ldg<br>TDZE <b>1073</b><br>Apt Elev <b>1073</b> |
|-----------------------------------------------------|------------------------|-----------------------------------------------------|

ILS or LOC RWY 17  
SHAWNEE RGNL (SNL)

|                        |           |                                                                                                                                                                      |
|------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DME or RADAR required. | MALSR<br> | MISSED APPROACH: Climb to 1600 then climbing right turn to 3000 on heading 009° and IRW R-073 to NESIY/I-HNQ 6.2 DME/RADAR and hold, continue climb-in-hold to 3000. |
|------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                            |                                           |                               |
|----------------------------|-------------------------------------------|-------------------------------|
| AWOS-3PT<br><b>118.275</b> | OKE CITY APP CON<br><b>120.45 288.325</b> | UNICOM<br><b>122.7 (CTAF)</b> |
|----------------------------|-------------------------------------------|-------------------------------|

