

NOTE: Chart not to scale.

VCOA RUNWAYS 10L/R: Obtain ATC approval for VCOA when requesting IFR clearance. Climb in visual conditions to cross Boise Air Trml/Gowen Fld at or above BOI VORTAC MEA/MCA before proceeding on assigned route of flight.