

VOR/DME FBR	APP CRS	Rwy Ldg	6404
114.45	215°	TDZE	7018
Chan 91(Y)		Apt Elev	7038

VOR RWY 22
FORT BRIDGER (FBR)

NA Circling NA to Rwys 7 and 25. When local altimeter setting not received, use Evanston altimeter setting and increase all MDAs 100 feet, increase S-22 Cats C and D and Circling Cat C visibility ¼ SM, and Circling Cat D visibility ½ SM.	MISSED APPROACH: Climbing right turn to 9000 in FBR VOR/DME holding pattern.
---	---

AWOS-3PT 118.8	SALT LAKE CENTER 124.35 353.5	UNICOM 122.8 (CTAF) 0
-------------------	----------------------------------	--------------------------

