

DEPARTURE ROUTE DESCRIPTION	
TAKEOFF RUNWAY 13: Climb on heading 129° to 1800 before turning westbound. TAKEOFF RUNWAY 17: Climb on heading 174° to 2600 before turning westbound. TAKEOFF RUNWAY 31: Climb on heading 309° to 1500 before turning southbound. TAKEOFF RUNWAY 35: Climb on heading 354° to 1400 before turning southbound. Fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitude. BELCHER TRANSITION (DALL4.EIC): From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to EIC VORTAC. LITTLE ROCK TRANSITION (DALL4.LIT): From over TTT VOR/DME on TTT R-064 to ORTRO, then on LIT R-237 to LIT VORTAC. SOLDO TRANSITION (DALL4.SOLDO): From over TTT VOR/DME on TTT R-084 to SOLDO. TEXARKANA TRANSITION (DALL4.TXK): From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.	