

VORTAC SGF 116.9 Chan 116	APP CRS 196°	Rwy Ldg 7003 TDZE 1262 Apt Elev 1268
---	------------------------	---

VOR or TACAN RWY 20
SPRINGFIELD-BRANSON NTL (SGF)

DME required.

	Rwy 20 helicopter visibility reduction below $\frac{3}{4}$ SM NA. For inop ALS, increase S-20 Cat E to 1% SM. VDP NA when using HFJ altimeter setting. When local altimeter setting not received, use HFJ altimeter setting: increase all MDAs 100 feet; increase S-20 visibility Cats C, D and E $\frac{1}{4}$ SM, and Circling visibility Cat C and D $\frac{1}{2}$ SM. For inop ALS, use HFJ altimeter setting: increase S-20 visibility Cats C, D and E to $\frac{1}{4}$ SM.
---	---

MALS

 $\textcircled{A_4} - \text{---}$

MISSED APPROACH: Climb to 3000 then right turn to intercept SGF R-206 to BILIE INT/SGF 21.8 DME and hold.

ATIS 135.125	SPRINGFIELD APP CON 124.95 290.5	SPRINGFIELD TOWER 119.9 257.8	GND CON 121.9 251.15	CLNC DEL 123.675
-----------------	-------------------------------------	----------------------------------	-------------------------	---------------------

