

|                        |          |             |
|------------------------|----------|-------------|
| APP CRS<br><b>101°</b> | Rwy Ldg  | <b>8016</b> |
|                        | TDZE     | <b>10</b>   |
|                        | Apt Elev | <b>10</b>   |

RNAV (GPS) RWY 10

LUIS MUNOZ MARIN INTL (SJU)(TJSJ)

**WAAS VNAV NA.** For uncompensated Baro-VNAV systems, LNAV/VNAV NA below -15°C (5°F) or above 54°C (130°F). DME/DME RNP-0.3 NA. For inop MALSR, increase LNAV/VNAV visibility all Cats to 1¼ and increase LNAV Cats C/D visibility to 1⅓.

MALSR

MISSED APPROACH: Climb to 500 then climbing left turn to 3000 direct DEEDY and hold.

|                        |                                                                                         |                                       |                               |                                |       |
|------------------------|-----------------------------------------------------------------------------------------|---------------------------------------|-------------------------------|--------------------------------|-------|
| D-ATIS<br><b>125.8</b> | SAN JUAN APP CON<br><b>119.4 269.2</b> (WEST & SW)<br><b>120.9 290.2</b> (NORTH & EAST) | SAN JUAN TOWER<br><b>132.05 257.8</b> | GND CON<br><b>121.9 348.6</b> | CLNC DEL<br><b>126.4 284.6</b> | CPDLC |
|------------------------|-----------------------------------------------------------------------------------------|---------------------------------------|-------------------------------|--------------------------------|-------|

