


AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)
JACKSONVILLE, FLORIDA


D-ATIS
125.85
JACKSONVILLE TOWER
118.3 317.7
GND CON
121.9 348.6
CLNC DEL
119.5 290.275
PDC



JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

SE-3, 15 JUL 2021 to 12 AUG 2021

SE-3, 15 JUL 2021 to 12 AUG 2021



RWY 08-26
PCN 76 R/B/W/T
S-120, D-250, 2D-485, 2D/2D2-1005

RWY 14-32
PCN 88 R/C/W/T
S-120, D-250, 2D-480, 2D/2D2-1000

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

81°42'W

81°41'W