

AIRPORT DIAGRAM

GREENVILLE SPARTANBURG INTL (GSP)
GREER, SOUTH CAROLINA


AL-5124 (FAA)

ATIS
134.25
GREER TOWER*
120.1 251.15
GND CON
121.9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SE-2, 09 SEP 2021 to 07 OCT 2021

SE-2, 09 SEP 2021 to 07 OCT 2021



JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

BLAST PAD
400 X 220

FIELD
ELEV
964

CUSTOMS

NORTH CARGO

CENTER CARGO

HANGARS

FIRE STATION

TWR

PASSENGER TERMINAL

SOUTH CARGO

ELEV
941

NWS

BLAST PAD
400 X 220

RWY 04-22
PCN 65 R/B/W/T
S-100, D-210, 2D-625,
2D/2D2-975

82°14'W

82°13'W

82°12'W

AIRPORT DIAGRAM

GREER, SOUTH CAROLINA
GREENVILLE SPARTANBURG INTL (GSP)