


21168

# AIRPORT DIAGRAM

BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)  
AL-61 (FAA)  
BROWNSVILLE, TEXAS

ATIS  
128.55  
BROWNSVILLE TOWER★  
118.9 239.3  
GND CON  
121.9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBCK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.



SC-3, 30 DEC 2021 to 27 JAN 2022

SC-3, 30 DEC 2021 to 27 JAN 2022

RWY 13-31  
PCN 67 R/D/X/T  
S-75, D-170, 2D-240

RWY 18-36  
PCN 7 F/C/X/T  
S-75, D-144, 2D-150

VAR 3.8° E  
 JANUARY 2020  
 ANNUAL RATE OF CHANGE  
 0.1° W

# AIRPORT DIAGRAM

21168

BROWNSVILLE, TEXAS  
BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)