


GUSTAVUS (GST)(PAGS) GUSTAVUS, ALASKA



<u>VCOA ALL RUNWAYS:</u> Obtain ATC approval for VCOA when requesting IFR clearance. Climb in visual conditions to cross GUSTAVUS airport southeast bound at or above 1500, continue climb to at or above 4000 on SSR R-297 to SSR VORTAC.