

# AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)

BIRMINGHAM, ALABAMA

ATIS 119.4 270.1  
 BIRMINGHAM TOWER 119.9 317.725  
 GND CON 121.7 348.6  
 CLNC DEL 125.675 305.2


D

RWY 06-24  
 PCN 65 F/C/X/T  
 S-175, D-205, 2D-350  
 RWY 18-36  
 PCN 45 F/C/X/T  
 S-75, D-170, 2D-240

JANUARY 2020  
 ANNUAL RATE OF CHANGE  
 0.1° W

SE-4, 05 SEP 2024 to 03 OCT 2024

SE-4, 05 SEP 2024 to 03 OCT 2024



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

# AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA  
BIRMINGHAM-SHUTTLESWORTH INTL (BHM)