

23334

AIRPORT DIAGRAM

JACKSONVILLE NAS (TOWERS FLD) (KNIP)

JACKSONVILLE, FLORIDA

[USN]

ATIS 124.35 290.425
 NAVY JACKSONVILLE TOWER
 125.15 (CTAF) 340.2
 GND CON
 128.6 336.4
 CLNC DEL
 134.775 353.675

30°15'N



OCTOBER 2019
 ANNUAL RATE OF CHANGE
 0.1° W

NORTH-SOUTH REF LINE

FLYING CLUB

FIELD ELEV 23

CALA

C

D

COMPASS ROSE

FIRE STATION

D1

C1

C

E-28

9003 x 200

E-28

ELEV 8

28

1000

x 100

30°14'N

095.7°

275.7°

10

A1

A2

A3

A3

A4

A4

A5

A5

A6

A6

A7

A7

B

B

H

H

511

VP-30 HANGAR

HOT REFUEL PITS

HANGAR 1000

Rwy 10-28 PCN 66 F/A/W/T

Rwy 14-32 PCN 30 F/B/W/T

Rwy 10 ldg 8006'

Rwy 14 ldg 3244'

180 WATER TOWERS

P-3 WASHRACK

HANGARS

116

1002

117

ELEV 15

PAX TRML

HOT REFUEL PIT

CONTROL TOWER/BASE OPS

HELO WASHRACK

ELEV 10

1122

124

140

FRC HANGAR

30°13'N

81°41'W

81°40'W

AIRPORT DIAGRAM

JACKSONVILLE, FLORIDA

JACKSONVILLE NAS (TOWERS FLD) (KNIP)

SE-3, 05 SEP 2024 to 03 OCT 2024

SE-3, 05 SEP 2024 to 03 OCT 2024