

AIRPORT DIAGRAM

AL-556 (FAA)

AUSTIN-BERGSTROM INTL (AUS)

AUSTIN, TEXAS

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

D-ATIS 124.4
 AUSTIN TOWER 121.0 281.5
 GND CON 121.9 348.6
 CLNC DEL 125.5 263.0
 CPDLC
 PDC



SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

Ramp Frequency: 126.225

JANUARY 2020 ANNUAL RATE OF CHANGE 0.1° W

FIELD ELEV 542

88L

0.6% DOWN

175.1°

TERMINAL

ELEV 18L 492

175.1°

HANGARS

MAINTENANCE RAMP

TWR 727

HS 1

SOUTH TERMINAL

HANGARS

FBO HANGARS

FBO HANGARS

HANGARS

FBO

12250 X 150

9000 X 150

0.3% UP

ELEV 36L 487

355.1°

355.1°

ELEV 36R 474

RWY 18L-36R
 PCN 92 R/B/W/T
 S-75, D-210, 2D-618, 2D/2D2-913
 RWY 18R-36L
 PCN 98 R/B/W/T
 S-75, D-210, 2D-618, 2D/2D2-913

SC-3, 31 OCT 2024 to 28 NOV 2024

SC-3, 31 OCT 2024 to 28 NOV 2024

AIRPORT DIAGRAM

AUSTIN-BERGSTROM INTL (AUS)

AUSTIN, TEXAS