

20086

# AIRPORT DIAGRAM

AL-5165 (FAA)

SPRINGDALE MUNI (ASG)  
SPRINGDALE, ARKANSAS

AWOS-3  
124.675  
SPRINGDALE TOWER ★  
118.2  
GND CON  
121.6

94°07.5'W

94°07.0'W

FIELD  
ELEV  
1353

36°11.0'N

81 ELEV  
1339

A1

A2

A3

A4

A5

A6

A

A

A

A

A

A

A

A

A

A

A

A

A

A

A

A

A

A

A

B1

B2

B3

B4

B5

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

B

185.8°

HAZARDOUS  
CARGO

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS

HANGARS


HANGARS

HANGARS

HANGARS

HANGARS

HANGARS



36°10.5'N

HANGARS

TERMINAL

TWR  
1436

HANGARS

HANGARS

RWY 18-36  
S-35, D-50, 2D-90

36 ELEV  
1352

5302 X 76

005.8°

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

36°10.0'N

# AIRPORT DIAGRAM

20086

SPRINGDALE, ARKANSAS  
SPRINGDALE MUNI (ASG)

SC-1, 31 OCT 2024 to 28 NOV 2024

SC-1, 31 OCT 2024 to 28 NOV 2024