

AIRPORT DIAGRAM

BELLINGHAM INTL (BLI)
BELLINGHAM, WASHINGTON

AL-45 (FAA)

ATIS
134.45
BELLINGHAM TOWER ★
124.9 379.3
GND CON
127.4 379.3

D

ELEV
163
9L
B

163.9°

48°48.0'N

RWY 16-34
PCN 57 F/A/W/T
S-75, D-160, 2D-250

VAR 15.9° E
JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W

HS 1

6700 X 150

- CARGO
- COMMERCIAL AIRCRAFT PARKING
- COMMERCIAL TERMINAL
- US CUSTOMS
- TWR 247
- FBO/GENERAL AVIATION TERMINAL
- TRANSIENT PARKING
- GENERAL AVIATION HANGARS
- HANGAR
- FIRE STATION

FIELD
ELEV
171
G

343.9°

34

NOTE: THIS AREA NOT VISIBLE FROM TOWER

48°47.0'N

122°32.5'W

122°32.0'W

122°31.5'W

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

BELLINGHAM, WASHINGTON
BELLINGHAM INTL (BLI)

NW-1, 23 JAN 2025 to 20 FEB 2025

NW-1, 23 JAN 2025 to 20 FEB 2025