

# AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)  
JACKSONVILLE, FLORIDA

D-ATIS  
125.85  
JACKSONVILLE TOWER  
118.3 317.7  
GND CON  
121.9 348.6  
CLNC DEL  
119.5 290.275  
CPDLC  
PDC


SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

JANUARY 2020  
ANNUAL RATE OF CHANGE  
0.1° W

FIELD  
ELEV  
30

SE-3, 20 MAR 2025 to 17 APR 2025

SE-3, 20 MAR 2025 to 17 APR 2025



RWY 08-26  
PCR 970 R/A/W/T  
S-120, D-250, 2D-550, 2D/2D2-1120  
RWY 14-32  
PCR 1380 R/B/W/T  
S-120, D-250, 2D-550, 2D/2D2-1120

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READEBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

81°42'W

81°41'W