


25107

AIRPORT DIAGRAM

BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)
AL-61 (FAA)
BROWNSVILLE, TEXAS

ATIS
128.55
BROWNSVILLE TOWER★
118.9 239.3
GND CON
121.9

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.



SC-3, 17 APR 2025 to 15 MAY 2025

SC-3, 17 APR 2025 to 15 MAY 2025

RWY 13-31
PCN 67 R/D/X/T
S-75, D-170, 2D-240

RWY 18-36
PCN 7 F/C/X/T
S-75, D-144, 2D-150

JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

97°26'W

97°25'W

AIRPORT DIAGRAM

25107

BROWNSVILLE, TEXAS
BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)