

ATTENTION ALL USERS PAGE (AAUP)

(CONTINUED FROM PREVIOUS PAGE)

5. SPECIFIC INFORMATION: FLL will use simultaneous departures from 0600 to 2230 local each day on runways 10L/R, 28L/R. All RNAV equipped aircraft departing should expect to fly an FLL RNAV DEPARTURE SID 24 hours a day, using only runway 10L/28R between the hours of 2230-0600. In the event of weather or other non-standard events, headings may be issued in lieu of an RNAV off the ground take off clearance.

- Final runway assignments will be issued on initial contact with Ground Control
- For planning purposes, pilots can anticipate the preferred runway assignment based upon the information below

Departures to the WEST

Departing Runway 28R
AGERS, FEALX, REGAE, SNAPR,
FRSBE, DORLL, LIFRR
 Departing Runway 28L
BNICE, GLADZ, HROCK, MAYNR

Departures to the EAST

Departing Runway 10L
AGERS, BNICE, GLADZ, HROCK,
FRSBE, DORLL, LIFRR
 Departing Runway 10R
FEALX, REGAE, SNAPR, MAYNR

