DSNEE THREE ARRIVAL (RNAV) Transition Routes

(DSNEE.DSNEE3) 01FEB18

LONG BEACH, CALIFORNIA

DSNEE THREE ARRIVAL (RNAV) Transition Routes

(DSNEE.DSNEE3) 18032

LONG BEACH, CALIFORNIA

AL-236 (FAA)

EMLLD TRANSITION (EMLLD.DSNEE3)
FEYLA TRANSITION (FEYLA.DSNEE3)
HIMDU TRANSITION (HIMDU.DSNEE3)
LRSON TRANSITION (LRSON.DSNEE3)
MARUE TRANSITION (MARUE.DSNEE3)
NATEE TRANSITION (NATEE.DSNEE3)
NEEDLES TRANSITION (EED.DSNEE3)

SOCAL APP CON
134.0 278.3
LONG BEACH ATIS
127.75
JOHN WAYNE AIRPORT-
ORANGE COUNTY D-ATIS
126.0

NOTE: RADAR required.
NOTE: RNAV 1.
NOTE: DME/DME/IRU or GPS required.
NOTE: Turbojet and turboprop aircraft only.
NOTE: Procedure is only for use when SNA is landing south.
NOTE: Landing LGB expect Runway 30 unless otherwise assigned by ATC.
NOTE: Landing SNA expect Runway 20R unless otherwise assigned by ATC.
NOTE: Expect local area altimeter reaching FL230.
NOTE: FEYLA transition restricted to LAS departures only.
NOTE: LRSON transition ATC assigned only.

N

NATEE
FEYLA
17000 214° (35)
SCROW
17000 239° (24)
MARUE
FJAYY
17000 239° (22)
059° 10 NM
17000 212° (30)
17000 239° (29)
LRSON FL280
GITRR FL250 280K
17000 212° (17)
DUUNN FL200
13000 205° (15)
CARZZ 15000
13000 210° (14)
AASPN 14000
10800 210° (6)
KADYN 13000
10800 197° (7)
EROCK 12000
9000 190° (11)
LUQAS 11000
8000 215° (6)
(11) 8000 216°
See following page for Arrival Routes.
DSNEE 8000 220K
8000 248° (23)
PHIYA 14000 12000
10700 249° (11)
ROADE FL190 17000
13000 247° (11)
BRCKK FL210
13000 248° (11)
CHURO FL240 280K
13000 248° (6)
DRTHI
261° 17000 (28)
WTTCH FL300
MDLER
10 NM 039° 219°
(32) 17000 247°
FOVOL
NEEDLES EED
17000 218° (30)
ONLYY
(39) 17000 218°
HIMDU
17000 241° (15)
17000 241° (20) WEELL
17000 241° (14) WURMO
17000 241° (32) THERS
17000 264° (37)
LITNG
084° 10 NM
17000 264° (39)
EMLLD

(CONTINUED ON FOLLOWING PAGE)

NOTE: Chart not to scale.