

ARRIVAL ROUTE DESCRIPTION

FORT WAYNE TRANSITION (FWA.HEDEE4): From over FWA VORTAC via FWA R-134 to OSBER, then via FWA R-134 and ROD R-314 to ROD VORTAC, then via ROD R-169 to HEDEE. Thence. . . .

ROSEWOOD TRANSITION (ROD.HEDEE4): From over ROD VORTAC via ROD R-169 to HEDEE. Thence. . . .

. . . .From over HEDEE on CVG R-052 (MEA 4000) to JADAT, expect radar vectors to final approach course at JADAT.

LOST COMMUNICATION PROCEDURE

CINCINNATI MUNI/LUNKEN FLD - At JADAT, turn right to intercept CVG VORTAC R-059 to WUSPU and hold, maintain 4000.

CLERMONT COUNTY - At JADAT, proceed to SPORTYS (PWF) NDB, maintain 4000 until SPORTYS (PWF) NDB.

GENE SNYDER - At JADAT, proceed to CVG VORTAC then on V517 to FLM VOR/DME, maintain 4000 until FLM VOR/DME.

EC-2, 07 OCT 2021 to 04 NOV 2021

EC-2, 07 OCT 2021 to 04 NOV 2021