

TOP ALTITUDE:

7000

ATIS

119.25

GND CON

120.875 348.6

MONTEREY TOWER ★

118.4 257.8

NORCAL DEP CON

133.0 251.15 (001°-135°)

127.15 307.125 (136°-360°)



WOODSIDE

113.9 OSI

Chan 86



SAN JOSE

114.1 SJC

Chan 88

SALINAS

117.3 SNS

Chan 120

PANOCHÉ

112.6 PXN

Chan 73



060°

R-210

BIG SUR

114.0 BSR

Chan 87

TAKEOFF MINIMUMS

Rwys 10L/R: Standard with minimum climb of 449' per NM to 4600.

NOTE: Takeoff Rwys 28L/R NA.

NOTE: Chart not to scale.

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAYS 10L/R: Climbing left turn heading 060°. Expect vectors to filed route after passing SNS R-210. Maintain 7000 or assigned altitude. Expect clearance to filed altitude five minutes after departure.

LOST COMMUNICATIONS: If no transmissions are received within one minute after departure, climb direct SNS VORTAC, then via assigned fix/route. Maintain 7000.