

## CONTINUED FROM PRECEDING PAGE

AIRSPACE: CLASS B See VFR Terminal Area Chart.

RADIO AIDS TO NAVIGATION: NOTAM FILE ADW.

ANDREWS (L) (L) VORTACW 113.1 ADW Chan 78 N38°48.43' W76°51.98' at fld. 263/10W.

VOR unusable:

035°-045° blo 2,500'

089°-182°

183°-227° blo 4,000'

230°-236° byd 20 NM

237°-270°

333°-048°

TACAN AZIMUTH unusable:

035°-045° blo 2,500'

220°-280°

295°-310°

DME unusable:

035°-045° blo 2,500'

220°-280°

ILS 111.5 I-RWS Rwy 01L. Class IIIE.

ILS 110.5 I-VJM Rwy 01R. Class IE.

ILS 110.5 I-GQZ Rwy 19L. Class IE.

ILS 111.5 I-MXK Rwy 19R. Class IIIE. LOC unusable 25° right of course.

---

**KENTMORR AIRPARK** (See STEVENSVILLE on page 115)

---

**LAYTONSVILLE**

DAVIS (W50) 3 N UTC-5(-4DT) N39°14.59' W77°09.05'

WASHINGTON

609 TPA-1409(800) NOTAM FILE DCA

RWY 08-26: H2600X50 (ASPH) 0.8% up E

RWY 08: Trees.

RWY 26: Trees.

SERVICE: S2 FUEL 100LL

AIRPORT REMARKS: Attended Mon-Fri dawn-dusk. Arpt closed dusk-dawn. Birds and wildlife on and invof arpt. Touch and go ops NA. Rwy 26, pond 80 ft R of thr.

AIRPORT MANAGER: 301-253-2897

COMMUNICATIONS: CTAF/UNICOM 122.8

CLEARANCE DELIVERY PHONE: For CD etc Potomac Apch at 866-429-5882.

COMM/NAV/WEATHER REMARKS: UNICOM unmon.

---

**LEE** (See ANNAPOLIS on page 90)

---