



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 14: Climbing right turn direct MEF NDB, depart MEF NDB bearing 066° to BRUTE INT. Thence. . . .

TAKEOFF RUNWAY 32: Climbing right turn heading 060° and OED VORTAC R-098 to BRUTE INT. Thence. . . .

. . . . via (transition) or (assigned route). Maintain 11000 or assigned altitude.

COPPO TRANSITION (BRUTE7.COPPO): From over BRUTE INT on OED VORTAC R-098 to LANKS DME, then on the OED VORTAC 15 DME Arc CW to COPPO DME.

CUTTR TRANSITION (BRUTE7.CUTTR): From over BRUTE INT on MEF NDB 063° to CEROS INT, then on the OED VORTAC 15 DME Arc CCW to CUTTR DME.

DREWS TRANSITION (BRUTE7.DREWS): From over BRUTE INT on MEF NDB 063° to CEROS INT, then on the OED VORTAC 15 DME Arc CCW to DREWS DME.

GRENA TRANSITION (BRUTE7.GRENA): From over BRUTE INT on OED VORTAC R-098 to LANKS DME, then on the OED VORTAC 15 DME Arc CW to JADUN DME, then on OED VORTAC R-138 to GRENA DME.

HANDY TRANSITION (BRUTE7.HANDY): From over BRUTE INT on OED VORTAC R-098 to LANKS DME, then on the OED VORTAC 15 DME Arc CW to HANDY DME.

LANKS TRANSITION (BRUTE7.LANKS): From over BRUTE INT on OED VORTAC R-098 to LANKS DME.

MOURN TRANSITION (BRUTE7.MOURN): From over BRUTE INT on MEF NDB 063° to CEROS INT, then on the OED VORTAC 15 DME Arc CCW to UZEHE DME, then on OED VORTAC R-333 to MOURN INT.

TALEM TRANSITION (BRUTE7.TALEM): From over BRUTE INT on OED VORTAC R-098 to LANKS DME, then on the OED VORTAC 15 DME Arc CW to LIPWO DME, then on OED VORTAC R-157 to TALEM DME.

UZEHE TRANSITION (BRUTE7.UZEHE): From over BRUTE INT on MEF NDB 063° to CEROS INT, then on the OED VORTAC 15 DME Arc CCW to UZEHE DME.

NW-1, 12 SEP 2019 to 10 OCT 2019

NW-1, 12 SEP 2019 to 10 OCT 2019