

	DEPARTURE ROUTE DESCRIPTION
	<u>TAKEOFF RUNWAYS 13L/R:</u> Climb on heading 133°, thence.on vectors to appropriate route. Maintain ATC assigned altitude and expect filed altitude 10 minutes after departure. <u>TAKEOFF RUNWAYS 31L/R:</u> Climb on heading 313° until the LVF or OVW localizer 5.5 DME, then right turn heading 013° for vector to the appropriate route, thence.maintain ATC assigned altitude and expect filed altitude 10 minutes after departure. <u>ABILENE TRANSITION (WORTH9.ABI):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC. <u>CHILDRESS TRANSITION (WORTH9.CDS):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC. <u>CORONA TRANSITION (WORTH9.CNX):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC. <u>LUBBOCK TRANSITION (WORTH9.LBB):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC. <u>PANHANDLE TRANSITION (WORTH9.PNH):</u> From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC. <u>PODDE TRANSITION (WORTH9.PODDE):</u> From over TTT VOR/DME on TTT R-250 to PODDE. <u>TEXICO TRANSITION (WORTH9.TXO):</u> From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.

SC-2, 01 DEC 2022 to 29 DEC 2022

SC-2, 01 DEC 2022 to 29 DEC 2022