

DEPARTURE ROUTE DESCRIPTION
<p><u>TAKEOFF ALL RUNWAYS:</u> Fly assigned heading for RADAR vectors to join filed/assigned route. Turbojet aircraft maintain 7000 or lower assigned altitude, all other aircraft maintain 5000 or lower assigned altitude. Expect clearance to assigned altitude/flight level ten minutes after departure.</p> <p><u>DME EQUIPPED AIRCRAFT RUNWAYS 12L/R DEPARTURES:</u> For assigned heading from 060°clockwise to 100°, cross MSP 7 DME at or above 3500. Maintain assigned altitude, if unable to comply advise ATC as soon as possible prior to departure.</p> <p><u>NON-DME EQUIPPED AIRCRAFT RUNWAYS 12L/R DEPARTURES:</u> For assigned headings from 060° clockwise to 100°, cross FGT R-010 at or above 3500, maintain assigned altitude. If unable to comply, advise ATC as soon as possible prior to departure.</p> <p><u>TAKEOFF RUNWAY 17 DEPARTURES:</u> For assigned headings from 230° clockwise to 285° cross MSP 7 DME at or above 3500, maintain assigned altitude. If unable to comply, advise ATC as soon as possible prior to departure.</p> <p><u>TAKEOFF RUNWAYS 30L/R DEPARTURES:</u> For assigned headings from 220° clockwise to 360° cross MSP 7 DME at or above 3500, maintain assigned altitude. If unable to comply, advise ATC as soon as possible prior to departure.</p>