


VOR/DME	MLB	Rwy Idg	9482
115.85	APP CRS	TDZE	26
Chan 105 (Y)	288°	Apt Elev	33

VOR RWY 27L
MELBOURNE ORLANDO INTL (MLB)

V A			MISSED APPROACH: Climb to 1000 then climbing left turn to 2100 direct MLB VOR/DME and hold.			
ATIS 132.55	ORLANDO APP CON 132.65 281.425	MELBOURNE TOWER ★ 118.2(CTAF) 0 257.8	GND CON 121.9	CLNC DEL 121.9	CLNC DEL 132.65 (When twr closed)	UNICOM 122.95



ELEV	33	D	TDZE	26
------	----	---	------	----

