


LOC/DME BC RWY 10
NOME (OME) (PAOM)

MISSED APPROACH: Climb to 3000
direct OME VOR/DME and hold,
continue climb-in-hold to 3000.

DME REQUIRED



BACK COURSE

MRL Rwy 3-21 **L**
 HRL Rwy 10-28 **L**
 REIL Rwy 3 and 10 **L**

