



LOC/DME I-OTH	APP CRS	Rwy Idg	5320
108.5	046°	TDZE	16
Chan 22		Apt Elev	17

ILS Z or LOC Z RWY 5
SOUTHWEST OREGON RGNL (OTH)

DME required.			MISSED APPROACH: Climb to 500 then climbing left turn to 2600 on heading 340° and OTH VOR/DME R-301 to YICBU/OTH 8 DME and hold, continue climb-in-hold to 2600.
	Circling Rwy 13, 31 NA at night.		

AWOS-3PT 135.075	SEATTLE CENTER 127.55 254.35	NORTH BEND TOWER★ 118.45 (CTAF)0	GND CON 127.1
----------------------------	--	---	-------------------------



One Minute Holding Pattern MITUE I-OTH 13.4 OTH 16 4500 ← 226° 1600 → 046° GS 3.00° TCH 51		Use I-OTH DME when on the localizer course. OXVAK I-OTH 4.9 EMIRE I-OTH 3.7 I-OTH 2.1 I-OTH 1		500 ↑ 2600 hdg 340°	OTH R-301 OTH 8	YICBU OTH 8
8.5 NM		1.3 NM	1.6 NM	1 NM		
CATEGORY	A		B	C	D	
S-ILS 5	216-½ 200 (200-½)					
S-LOC 5	400-½ 384 (400-½)			400-⅝ 384 (400-⅝)		
CIRCLING	680-1 663 (700-1)	820-1 803 (900-1)	1080-3 1063 (1100-3)	1160-3 1143 (1200-3)		