




HI-VOR or TACAN RWY 5L

VORTAC VXV 116.4 Chan 111		APCH CRS 045°		Rwy Idg 9508 TDZE 953 Arpt Elev 986		[USAF]		MC GHEE TYSON (KTSY)	
DME required ▼ *When ALS inop, increase vis to 1½ miles.					MALSR 		MISSED APPROACH: Climb to 6000 direct to VXV VORTAC, then on VXV R-307 to WINNA/VXY 32 DME and hold.		
ATIS 128.35		KNOXVILLE APP CON 123.9 360.8		KNOXVILLE TOWER 121.2 257.8		GND CON 121.9 348.6		CLNC DEL 121.65	



EMERG SAFE ALT 100 NM 8900

ELEV	986	D	TDZE	953
HIRL Rwy 5R-23L, 5L-23R REIL Rwy 5R-23L TDZL/RCLS Rwy 5R, 23R				



HI-VOR or TACAN RWY 5L